




Jack 2000

Spare part list




Jack 2500

NUSSBAUM
HEBETECHNIK

Spare parts list

JACK 2500




Nr	Description	Code	Nr	Description	Code
1	hydraulic hose	980287	25	bolt of scissors lower s.	025JK06041
2	Screwed connection	980289	26	threaded pin	9G915M06X10ZN
3	air-oil pump	980286	27	carrying plate	025JK08003
4	hydraulic cylinder	025JK02001	28	blocking plate	015JK08014
5	base plate	025JK05003	29	cylinder screw	9Z912M08X10ZN
6	cylinder screw	9Z912M05X12ZN	30	pushing part	025JK08021
7	washer	9SC125M05ZN	31	pad	015JK08028
8	blocking plate	015JK05016	32	countersunk screw	9SE963M06X20ZN
9	rolling truck	025JK05030	33	hexagon nut	9MU934M06ZN
10	roller	018JK05030	34	elastomer support	901103031
11	needle bush	970325	35	elongation of cart. arm	015JK08034
12	ring inside	970328	36	carrying shoe	015JK08037
13	washer	9SC125M20ZN	37	rubber support	015JK08042
14	Seeger ring	9SR020X1.2	38	scissors outside	025JK06003
15	roll	025JK06012	39	ratchet	025JK10003
16	axle of roll	025JK06013	40	operating lever	018JK10019
17	Seeger ring	9SR020X1.2	41	guidance	018JK10025
18	slim. rlog	9SC988035X45X2	42	cylinder screw	9Z912M06X16ZN
19	circclip	9SC6796M20ZN	43	spring	9ZFZ-092ZN
20	scissors inside	025JK06021	44	cone	970233
21	cylinder screw	9Z912M20X20ZN	45	washer	9SC125M08ZN
22	bolt of scissors middle p.	025JK06039	46	slim ring	9SC988035X45X1
24	bolt of scissors top pos.	025JK06040			

NUSSBAUM
HERBTECHNIK

Spare parts list

JACK 2000





Nr	Description	Code	Nr	Description	Code
1	Rubber support	90110303J	21	traverse	020JK05035
2	pad	015JK08028	22	sliding piece lower side	020JK05044
3	elongation of pad	015JK08034	23	sliding piece lateral	020JK05045
4	button "lifting"	020JK09010	24	bottom tub	020JK05001
5	button "lowering"	020JK09013	25	Block for lowering brake	020JK02015
6	carrying arm	020JK08010	26	pump support	020JK02018
7	rail	020JK08001	27	air-oil pump	980559
8	elongation of screwing in	020JK06017	28	covering lower side	020JK09006
9	axle of sliding piece	020JK06018	29	bolt	020JK10007
10	sliding piece upper/lower s	020JK06016	30	unlocking	020JK10003
11	scissors outside	020JK06003	31	DU-bearing	970458
12	circlip	020JK06035	32	cylinder hanging up	020JK06028
13	hinge bolt middle position	020JK06037	33	DU-bearing	970071
14	DU-bearing	979478	34	scissors inside	020JK06021
15	hinge bolt lower side	020JK06032	35	bolt of fixed bearing	020JK06040
16	bolt of fixed bearing	020JK05006	36	DU-bearing	970461
17	pressure plate	020JK06011	37	covering of pump	020JK09002
18	cylinder complete	020JK02001	38	connection	020JK10014
19	axle of cylinder upper s.	020JK06033	39	bearing of ratchet	020JK05038
20	sliding piece	see additional p.	40	distance J-profile	020JK05051

NUSBAUM
HEBELTECHNIK

Spare parts list: additional

JACK 2000

guiding for the UNI-LIFT 3500 and 4.35 H




Nr.:	Description	Code
A	traverse complet	020JK05400
B	traverse complet	020JK05410
1	traverse	020JK05401
1a	traverse	020JK05411
2	roll	020JK05404
	cylinder liner	020JK05403
	socket head cap screw	9Z912M08X030ZN
3	roll	020JK05407
	DU-liner	PAP1012P10
4	straight pin	9ZS710x020
5	socket head cap screw	9Z912M08X035ZN
6	pipe	020JK25077
7	holder of the sliding block	020JK05406

NUSSBAUM
HEBETECHNIK


Spare parts list: additional

JACK 2000

Additional spare parts list: guiding Jack 2000 (val.: Apr. 4th 96)



Lfd.Nr	Description	Code
1	traverse für U120	020JK25110
2	support of slide blocs	020JK25024
3	roll	020JK25113
4	roll	020JK25025
5	spring 1	025ALSM08041
6	bolt	025ALSM08039
7	spring 2	020JK25026



Hausgegend ist die Zeichnungsbemessung!

1 STUECK / BUEHNE





PASSEPASS		NUSSE ORT VORBEREITUNGEN D. 10.11.12 DEN 12.12.12		GEZEICHNE	MASSSTAB: 0:100	BEK. LICHT: 8.11.12
NAME		DATUM		NAME	BEMERKUNG	
LEB. 1		S. Dec-99		Nussbaum		
KEPER		IDEN		REBETECHNIK		
Firma		Nussbaum		ZEICHNUNGSRUMMER		
Nr. Veränderung		Datum		ERSATZ DURCH		
Name Inseph		Nussbaum		020JK05520		
				BLATT		
				1		

Anbindg. kompl.

(1KO)

Ed. Amano

Sliding panel
for the wall-lift cat
and wall-lift NT



Wassergehend ist die Zeichnungsbemessung:

[illegible]

Schweissnahtgüte: 11 DIN 1912 Bl. 1
Schweißverfahren: MAG² (E)
S-Zusatzwerkstoff: SG3 (Ti VIII s)
S-nahtstärke : a = x

NUSSBAUM
HEBETECHNIK

Spare parts list

JACK 2500

rolling truck for: **UNI-LIFT 5000**

0.50 ULN




Nr.	Description	Code	piece/lift
1	roll	025JK05060	4
	needle bush	970325	4
	inner raceway	970328	4
2	rolling truck	025JK05035	2

Version JAPAN

rolling truck for: **UNI-LIFT 3200**

UNI-LIFT 5000

3100 T




Nr.	Description	Code	piece/lift
1	roll	025JK05050	4
	needle bush	970325	4
	inner raceway	970328	4
2	rolling truck	025JK05055	2

NUSSBAUM
HEBETECHNIK

Spare parts list



JACK 2500

rolling truck for: **UNI-LIFT 3200**
UNI-LIFT 5000
3100 T



Nr.	Description	Code	piece/lift
	rolling truck complet	025JLK25028	2
1	Umgriff	025JK25035	2
2	roll .	025JK50050	1
	roll		
	(UNI-LIFT 3200 with lighting)	025JK05046	4
3	Nadelhülse	970325	4
	Innenring	970328	4
4	rolling track	025JK05030	2

rolling truck for: **2.50 TTA**



Nr.	Description	Code	pieces/lift
	rolling truck complet	025JK05301	2
1	roll		
	with needle bush	020JK05407	4
2	spring steel sheet	025ALSM08041	4
3	distance	020JK25075	2
4	spring steel sheet	020JK25026	2
5	spring steel sheet	020JK25026	2
6	roll	020JK25123	4
7	washer	020JK25042	4
8	rolling truck	025JK05303	2


NUSSEBAUM
HEBETECHNIK

Spare parts list

JACK 2500

rolling truck for: **UNI-LIFT 5000**


0.50 ULN



Nr	Description	Code	piece/lift
1	roll	025JK05060	4
	needle bush	970325	4
	inner raceway	970328	4
2	rolling truck	025JK05055	2

*** Version JAPAN**

rolling truck for: **UNI-LIFT 3200**
UNI-LIFT 5000
3100 T



Nr	Description	Code	piece/lift
1	roll	025JK05050	4
	needle bush	970325	4
	inner raceway	970328	4
2	rolling truck	025JK05055	2

you need a new
connection for the
UNI 3500. which are
built in Seehausen not
by Nussbaum Headquarter

you receive the
price and the
delivery time from
Annabelle Normann
I speak with Annabelle

P. Golutsky