


SPARE PARTS LIST


CORNO 920 NEW

AUTOMATIC TYRE CHANGER




No.	Code	Description
101	240516	Arm stop plate
102	424275	Washer Ø10,25x33x4
9026	228875	Rear piston + fitting including:
105	414842	90° fitting
110	339803	Spring bushing
111	339782	Roller
112	339786	Pin
114	336142	Horizontal clamp spring
115	341836	Screw M12x40
117	340430	Vertical arm
119	426763	Pipe guide
122	439787	Spring 22,6x22x2,3
125	326667	Top shaft raise cylinder pin
126	238534	Seal kit for arm control cylinder
128	431061	Bushing
129	426773	Ø60 cylinder guard
130	428681	Seal ring
9027	228880	Front piston + fitting including:
131	414859	T fitting
134	226477	HPT mount/demount head
135	225630	Arm control cylinder Ø95

No.	Code	Description
136	344989	Pin 18x132
137	328866	Cylinder Ø50
138	338858	Top pipe
139	238856	Support with pipe
140	338855	Shaft
141	327284	Rear plate
142	427290	Swivel fitting M5
143	327283	Front plate
144	428719	Screw M5
145	428720	Nylon washer
146	428718	Swivel ring M5
147	327753	Pipe throttle Ø0,65
148	331783	Pipe throttle Ø1,25
149	427299	Gasket Ø13
150	432090	Finder ring
151	440342	Spring 53x81x3,2
152	340429	Vertical lock plate
153	440428	Knob
154	440692	Handle extension
155	231744	Stopcock with handle




No.	Code	Description
600	323363	Washer Ø16.5x48x10
601	426514	Turntable plug
9019	242125	20" turntable assembly including:
602	242124	Sliding support
603	341283	Rubber bumper
604	340928	Chucking gripper
605	237951	Turntable
606	338216	Slot covering slide
607	438226	Spring 8.2x50
608	426346	Washer Ø65x85x1

No.	Code	Description
609	237923	Connecting rod control flange
610	337964	Nylon washer Ø18x25x5
611	337965	Bushing
612	242123	Sliding support (drive)
613	238548	Turntable cylinder seal kit
9020	237909	Left turntable cylinder including:
614	428593	L fitting 1/8"
9020	237910	Right turntable cylinder including:
614	428593	L fitting 1/8"
615	417408	Thread fitting 6/4"-1/8"




No.	Code	Description
9010	235572	110V Single Phase electric system incl.:
801	435363	Inverter 32A 600V
802	230709	Neoprene power network cord
803	225419	Motor connecting cord
804	225051	Ground wire connection
805	430750	Condenser cap Ø45
806	430713	Condenser 40MF 450VL
807	430770	Resistance 330Kohm 1W
9010	235573	220V Single Phase electric system incl.:
801	421523	Inverter
802	235520	Connecting cord
803	225419	Motor connecting cord
804	225051	Ground wire connection
805	414850	Condenser cap
806	425504	Condenser 30MF
807	417794	Resistance 330Kohm 1W

No.	Code	Description
9010	235574	3-Phase electric system including:
801	421523	Inverter
802	235518	Connecting cord
803	225390	Motor connecting cord
804	225051	Ground wire connection
808	431740	220V 50/60Hz single Phase motor
808	430666	115V 50/60Hz single Phase motor
808	422013	380V 50/60Hz 3-phase motor
808	425397	440V 50/60Hz 3-phase motor
809	432009	V belt A23
810	334768	Motor cradle mount
811	331067	Dual pulley Ø70-57
812	432065	Inverter guard
813	430991	Cover guard




No.	Code	Description
9018	233678	Foot pedal unit including:
301	422682	1/8" plastic muffler
302	325064	Pre-curved pipe
303	325019	Leafspring fork
304	425020	Dual cam
305	325018	Connecting rod U-bolt
306	425014	Cam connecting rod
307	325030	Post raise pedal
308	419888	Split ring Ø8.4x15
309	309358	Washer Ø8x16.5x0.5
310	325005	Pedal unit pin
311	410628	Spring Ø14x94x2

No.	Code	Description
312	325031	Turntable pedal
313	325032	Bead-breaker pedal
314	325050	Spacer
315	325029	Turn direction change pedal
316	425010	Turn direction change connecting rod
317	425027	Switch lever
318	332495	Direction changer U bolt
319	228522	Stopcock AU4
320	233676	Post raising stopcock
321	316199	Lockring Ø6
322	428682	Switch spring
323	433675	1/8" discharge regulator




No.	Code	Description
9401	233677	Air pedal assembly including:
401	229059	Air operated pedal cock
402	229957	Pedal air motor
403	322705	Rilsan hose (Ø8x1 L.220)
404	329058	Reverse pedal stop plate
405	330355	Rilsan hose (Ø8x1 L.120)
406	331381	Cock controlconnecting rod
407	415860	Fitting
408	332004	Motor cradle
409	425238	Toothed belt (L.100)
410	422288	Hex. nut (M6)

No.	Code	Description
411	319076	Pulley
412	419142	Nipples (1/4")
413	418350	90° fitting (10/8-1/8")
414	319135	Air motor
415	419140	Fitting (10/8-1/4")
416	419141	Exhaust valve
417	324639	Rilsan hose (M10x1x800)
418	319073	Pulley
419	419138	Muffler (1/4")
420	315273	Rilsan hose (Ø8x1 L.800)




No.	Code	Description
1	242102	Left side panel
2	342059	Footpedal guard
3	436199	Rim support
4	422019	Mount/Demount foot
5	318183	Washer Ø12.5x37.5x6
6	322348	Screw M10x20
7	320191	Screw M8x30

No.	Code	Description
8	331055	Post pin
9	339456	Pin
10	339046	Pin
11	417351	Handle
12	326169	Lube bracket
13	428845	Weight hammer holder
14	442121	Post guard




No.	Code	Description
9011	239042	Bead-breaking cylinder including:
501	418350	90° fitting 10/8"-1/8"
502	325561	Washer Ø24x29,8x0.5
503	434031	Ring
9012	239043	Bead-breaker assembly blade including:
504	224000	Blade
505	224003	Bead-breaking assembly
506	323901	Washer Ø8.25x40x3
507	339045	Swivel pin

No.	Code	Description
508	324008	Blade pin
509	409650	Split washer Ø12
510	422255	Lock nut M12
511	239061	Spacer
512	439105	Spring Ø23x120x3
513	323903	Bead-breaker arm fulcrum pin
514	425219	Handle
515	238212	Seal kit for bead-breaking cylinder




No.	Code	Description
201	438872	16 lt. tank
202	435077	Safety valve
203	241841	Air swivel valve
9023	239003	Inflating assembly + pedal including:
204	434921	Kingston valve 1/4" + nut
205	338684	Spring block
207	338576	Spacer 1/4"
208	438673	90° fitting 1/4"
209	438672	Fitting 1/4"
210	238708	Pedal
211	338685	Pin
1003	235463	Kit valve

No.	Code	Description
213	342286	Valve support bracket
218	438995	1" MF fitting
219	335299	Rubber bumper
220	435285	Tubeless tyre inflation nozzle
221	441598	90° fitting 1/4 10
222	441839	Fitting 1/4 10
223	337704	1" G. fitting
224	342288	Hose L.280
225	342289	Transparent Rilsan hose Ø14 L.640
9025	234762	Pressure gauge box including:
226	235462	Inflating hose
227	437831	Pressure gauge Ø80
228	235463	Kit valve
9024	242290	KPM valve assembly including:




No.	Code	Description
9701	243102	Gearbox including:
700	414344	Pulley
701	601280	Pin A8x20
702	601220	Bearing Ø50x80x16
704	601950	Key A6x6x18
706	601221	Taper roller bearing Ø20x47x15,25


No.	Code	Description
709	238204	Gearbox seal kit



No.	Code	Description
Ø6	701684	Rilsan hose Ø6x1 (m.)
Ø8	701683	Rilsan hose Ø8x1 (m.)
Ø10	701875	Rilsan hose Ø10x1 (m.)
1001	339425	Hose DI.6 DE.14 L.1600



No.	Code	Description
901	418529	Coupling 1/4"-1/4"
902	438673	90° coupling
903	433873	T coupling M 1/4"
9021	437231	Filter and lubricator assembly including:
904	439377	Filter cup
905	439376	Lubricator cup
906	434818	Pressure gauge Ø40 12BAR-PSI



No.	Code	Description
		Given as outfit:
1102	444288	Tyre lever
		Optional accessories:
1101	235745	8"-18" wheel adapter
1103	228563	Motorcycle mount/demount head
1104	225640	Motorcycle tyre bead-breaker

No.	Code	Description
1105	235225	15"-22" motorcycle wheel adapter
1106	435202	Motorcycle chucking gripper
1107	242613	Mount/demount head insert kit
1108	435685	Bead pressing pliers